


[Français](#)
[Home](#)
[Contact Us](#)
[Help](#)
[Search](#)
[canada.gc.ca](#)
[Transport Canada](#) > [CANUTEC](#) > [Emergency Response Guidebook 2008](#)

ERG 2008

[Canutec Home](#)
[ERG Online Home](#)
[Table of Contents](#)
[Search ERG](#)
[ID Number](#)
[Name of Material](#)
[Placards](#)
[Rail Car ID Chart](#)
[Road Trailer ID Chart](#)
[Guide Number](#)
[TIIPAD](#)
[Water Reactive Materials](#)
[Chemical Warfare Agents](#)
[Español](#)

GUIDE ALUMINUM (Molten) 169

POTENTIAL HAZARDS

FIRE OR EXPLOSION

- Substance is transported in molten form at a temperature above 705°C (1300°F).
- Violent reaction with water; contact may cause an explosion or may produce a flammable gas.
- Will ignite combustible materials (wood, paper, oil, debris, etc.).
- Contact with nitrates or other oxidizers may cause an explosion.
- Contact with containers or other materials, including cold, wet or dirty tools, may cause an explosion.
- **Contact with concrete will cause spalling and small pops.**

HEALTH

- Contact causes severe burns to skin and eyes.
- Fire may produce irritating and/or toxic gases.

PUBLIC SAFETY

- **CALL Emergency Response Telephone Number on Shipping Paper first. If Shipping Paper not available or no answer, refer to appropriate telephone number listed on the inside back cover.**
- As an immediate precautionary measure, isolate spill or leak area for at least 50 meters (150 feet) in all directions.
- Keep unauthorized personnel away.
- Ventilate closed spaces before entering.

PROTECTIVE CLOTHING

- Wear positive pressure self-contained breathing apparatus (SCBA).
- Wear flame retardant structural firefighters' protective clothing, including faceshield, helmet and gloves, this will provide limited thermal protection.

EMERGENCY RESPONSE

FIRE

- **Do Not Use Water, except in life threatening situations and then only in a fine spray.**
- **Do not use halogenated extinguishing agents or foam.**
- Move combustibles out of path of advancing pool if you can do so without risk.
- Extinguish fires started by molten material by using appropriate method for the burning material; keep water, halogenated extinguishing agents and foam away from the molten material.

SPILL OR LEAK

- Do not touch or walk through spilled material.
- Do not attempt to stop leak, due to danger of explosion.
- Keep combustibles (wood, paper, oil, etc.) away from spilled material.
- Substance is very fluid, spreads quickly, and may splash. Do not try to stop it with shovels or other objects.
- Dike far ahead of spill; use dry sand to contain the flow of material.
- Where possible allow molten material to solidify naturally.
- Avoid contact even after material solidifies. Molten, heated and cold aluminum look alike; do not touch unless you know it is cold.
- Clean up under the supervision of an expert after material has solidified.

FIRST AID

- Move victim to fresh air.
- Call 911 or emergency medical service.
- Give artificial respiration if victim is not breathing.
- Administer oxygen if breathing is difficult.

- For severe burns, immediate medical attention is required.
- Removal of solidified molten material from skin requires medical assistance.
- Remove and isolate contaminated clothing and shoes.
- In case of contact with substance, immediately flush skin or eyes with running water for at least 20 minutes.
- Keep victim warm and quiet.

Date Modified: 2011-11-16


[Top of Page](#)

[Important Notices](#)